


SKRD Daily Maintenance

Please turn off the exhaust fan before maintenance


Top Ring



Clean the top ring after use with a towel everyday at the close of business. Make sure to clean the back side as well.

Notice

Ceramic Charcoal




Brush the ceramic charcoal pieces everyday at the close of business.

DF




Sana Plate



Clean the sana plate, DF, and burner cover everyday at the close of business.

Burner Cover



Notice

Drain Pan



Please do not use Clean the drain pan everyday at the close of business.

Please do not use steel wool, alkaline cleaners or heavy detergents. This may cause the coating to peel or corrode.


Buner Head



Clean the burner head everyday at the close of business by brush.

✘If the fire hole is clogged, gas backflow may occur, resulting in an abnormal combustion accident.

Burner Body



Clean the burner body everyday at the close of business.

Use a wire brush to clean. Tap the burner periodically with a plastic hammer or wooden hammer to dislodge internal rust or dirt.

Debris Trap




Clean the debris trap everyday at the close of business.

3D Filter



Clean the 3D filter everyday at the close of business. It comes apart easily and is dishwasher safe.

Outer Casing




Notice

Clean the outer casing everyday at the close of business. Before cleaning, remove the 3D filter and then wash it with a neutral detergent using a dish sponge. Finally, wipe

FD (Fire Damper)

Connection drum



detergent using a dish sponge. Finally, wipe the area with a soft towel or rag.

Please do not use alkaline cleaners or heavy detergents. This may cause the coating to

The fire damper and connection drum that can be reached by hand: Wipe the grease with a damp cloth once a day. (The connection drum cannot be dismantled)



Shinpo America, Inc.

Support Desk: inquiry@shinpo-en.com

TEL: +1-925-223-8673 FAX: +1-925-399-6568

5820 Stoneridge Mall Rd., Suite 325 Pleasanton, CA 94588, USA

シンポ(株)海外事業部

TEL +81-3-5959-6761 FAX +81-3-5959-6830

東京都北区王子2-30-2 井門王子ビル8F

神府贸易（上海）有限公司

Tel +86 21-6278-9977 Fax +86 21-5234-0510

中国上海市长宁区娄山关路85号 东方国际大厦 13层 A座 06室